



Rail Brake

Generation II

RB15, RB20, RB25, RB30, RB35, and RB45



In accordance with Nexen's established policy of constant product improvement, the specifications contained in this manual are subject to change without notice. Technical data listed in this manual are based on the latest information available at the time of printing and are also subject to change without notice.

Technical Support: 800-843-7445
(651) 484-5900

www.nexengroup.com

	<p style="text-align: center;"> DANGER</p> <p>Read this manual carefully before installation and operation. Follow Nexen's instructions and integrate this unit into your system with care. This unit should be installed, operated and maintained by qualified personnel ONLY. Improper installation can damage your system, cause injury or death. Comply with all applicable codes.</p>	
-----------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------

This document is the original, non-translated, version.

Conformity Declaration: In accordance with Appendix II B of CE Machinery Directive (2006/42/EC):

A Declaration of Incorporation of Partly Completed Machinery evaluation for the applicable EU directives was carried out for this product in accordance with the Machinery Directive. The declaration of incorporation is set out in writing in a separate document and can be requested if required.

This machinery is incomplete and must not be put into service until the machinery into which it is to be incorporated has been declared in conformity with the applicable provisions of the Directive.

Nexen Group, Inc.
560 Oak Grove Parkway
Vadnais Heights, Minnesota 55127

ISO 9001 Certified

Copyright 2013 Nexen Group, Inc.

Table of Contents

General Specifications	4
General Safety Precautions	4
Installation	5
Required Tools.....	5
Air Connections.....	5
Accessories	5
Mounting on a Rail	6
Alignment Verification	7
Friction Facing Gap Adjustment	7
Friction Facing Replacement.....	8
Service Restrictions	8
Warranty	9


GENERAL SPECIFICATIONS

Specifications	
Holding Force:	Up to 2600 N (585 lbs)
Release Pressure:	5.5 bar (80 psi)
Service Temperature:	4.5 - 50 C (40 - 120 F)
Backlash:	See Tech Data Sheet
Engaged Time:	See Tech Data Sheet

GENERAL SAFETY PRECAUTIONS

	<p>CAUTION</p> <p>Watch for sharp features when installing and servicing the brake. The brake has complex and machined edges.</p>
-----------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------

	<p>WARNING</p> <p>Keep indoors. This product is intended for indoor environments only. Use of the brake outdoors will damage components.</p>
------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------






INSTALLATION

REQUIRED TOOLS

- Clean, pressurized air
- Mounting bolts and appropriate wrench
(See Table 1)

AIR CONNECTIONS

All Nexen pneumatically actuated devices require clean and dry air, which meet or exceeds ISO 8373.1: 2001 Class 4.4.3 quality.



ACCESSORIES

- 4 mm [5/32 inch] soft air tubing
- Air valve
- Quick exhaust valve (optional)




The Rail Brake is equipped with one air inlet port used to disengage the brake (Refer to Figure 2 for location).

NOTE: Clean air is important for proper Rail Brake functioning. Debris inside the Rail Brake may inhibit performance and/or decrease product life.

1. Route clean air to the Rail Brake using soft lines. Supply adequate air pressure to ensure complete disengagement.

NOTE: For faster engagement and disengagement, install the valve close to the Rail Brake. Increasing air pressures will also speed the disengagement time, but do not exceed 8.3 bar [120 psi] air pressure.



	IMPORTANT	
<p>Carefully follow Steps 1-4 to ensure a successful Rail Brake installation. Do not use the dowel pin holes for brake installation. These holes are for manufacturing purposes only.</p>		

MOUNTING ON A RAIL

Assembly Shims: This installation recommends the use of assembly shims to ensure proper alignment. The assembly shim is a .08mm (.003") rectangular shaped piece of shim stock that runs the full length of the facings. See Figure 4 for an example. Each shim will be different depending on rail type. The shim is customer provided and one is required for each side.

1. Disengage Brake.
 - a. **SPRING ENGAGED VERSION:** Apply minimum 5.5 BAR (80 PSI) to air inlet of brake to disengage. (Refer to AIR CONNECTIONS for details).
 - b. **AIR ENGAGED BRAKE:** Disengaged is the default position.
2. Using installation shims, slide brake onto rail with shims between the facing and the rail on both sides. The installation shims are approximately the same thickness as the gap between the facing and the rail. Because of this some drag is expected while completing this step.
3. Once brake is approximately in position, install mounting screws finger tight. Do not tighten at this point.
4. Engage Brake, this will center it on the rail, then tighten the mounting screws. Do not remove shims at this point.




Figure 4




Figure 5

*Customer Supplied

Table 1

Model	Socket Head Cap Screw Size
RB15	M5 x 0.8
RB20	M6 x 1.0
RB25	M8 x 1.25
RB30	M10 x 1.5
RB35	M10 x 1.5
RB45	M12 x 1.75




Figure 6

ALIGNMENT VERIFICATION




1. With the shims still in place, mounting bolts tightened, and brake disengaged, run the brake the full length of machine travel. If an alignment issue exists, the brake will drag at those spots where there is misalignment.
2. If an alignment issue is found re-adjust the rail per the manufacture's recommendations.
3. Remove shims.
4. Again by hand, run the brake the full length travel of the machine. NO drag should be felt between the facing and rail. If drag is experienced, repeat alignment steps.

FRICION FACING GAP ADJUSTMENT

Friction facing Gap adjustment should not be necessary as the gap is factory set to accommodate standard rail sizes and types. Before attempting to adjust the facing gap. Ensure the mounting and alignment processes are complete.

	 WARNING
	<p>To achieve rated holding force the rail brake must maintain a close fit between the facing and the rail (Under .127mm [.005in]). Adjusting the brake to have a gap wider than this will cause performance reductions.</p>

1. Disengage Brake.
2. Cut the label between the housing and the guide using a straight edge. Leave the label in place so it can act as a reference to the original position.
3. Adjust the position of the facing by turning the guides on each side of the counter clockwise. Notes regarding adjustment:
 - a. Make sure each side is turned an equal amount. Failure to do this could cause misalignment.
 - b. 1/8 of a turn is equivalent to approximately .127mm(.005in). There should be no need to adjust more than this amount.
4. Repeat mounting and alignment verification steps.



FRICION FACING REPLACEMENT



1. With load supported, remove the mounting screws from the brake.
2. Disengage brake.
3. Slide the rail brake off the rail.
4. Using a small pliers, remove the facing return springs.



5. Carefully remove facings, while the facing is off the components behind the facing are not retained. Use caution not to lose small parts.
6. Install new facings.
7. Again, using a small pliers, reinstall the facings return springs.

SERVICE RESTRICTIONS

NOTE: The Rail Brake assembly is designed for extended service life. Due to this long product life, stored spring energy, and the complexity of the internal components, Nexen recommends that all service be performed by trained personnel.

Do not attempt to remove or dismantle any part of the Rail Brake assembly. This product is spring loaded and under pressure. If the product malfunctions, replace the unit or contact Nexen.




Figure 10

WARRANTY

Warranties

Nexen warrants that the Products will (a) be free from any defects in material or workmanship for a period of 12 months from the date of shipment, and (b) will meet and perform in accordance with the specifications in any engineering drawing specifically for the Product that is in Nexen's current product catalogue, or that is accessible at the Nexen website, or that is attached to this Quotation and that specifically refers to this Quotation by its number, subject in all cases to any limitations and exclusions set out in the drawing. NEXEN MAKES NO OTHER WARRANTY, EXPRESS OR IMPLIED, AND ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. This warranty applies only if: (a) the Product has been installed, used and maintained in accordance with any applicable Nexen installation or maintenance manual for the Product; (b) the alleged defect is not attributable to normal wear and tear; (c) the Product has not been altered, misused or used for purposes other than those for which it was intended; and (d) Buyer has given written notice of the alleged defect to Nexen, and delivered the allegedly defective Product to Nexen, within one year of the date of shipment.

Exclusive Remedy

The exclusive remedy for the Buyer for any breach of any warranties provided in connection with this agreement will be, at the election of Nexen: (a) repair or replacement with new, serviceably used, or reconditioned parts or products; or (b) issuance of credit in the amount of the purchase price paid to Nexen by the Buyer for the Products.

Agent's Authority

Buyer agrees that no agent, employee or representative of Nexen has authority to bind Nexen to any affirmation, representation, or warranty concerning the Products other than those warranties expressly set forth herein.

Limitation on Nexen's Liability

TO THE EXTENT PERMITTED BY LAW NEXEN SHALL HAVE NO LIABILITY TO BUYER OR ANY OTHER PERSON FOR INCIDENTAL DAMAGES, SPECIAL DAMAGES, CONSEQUENTIAL DAMAGES OR OTHER DAMAGES OF ANY KIND OR NATURE WHATSOEVER, WHETHER ARISING OUT OF BREACH OF WARRANTY OR OTHER BREACH OF CONTRACT, NEGLIGENCE OR OTHER TORT, OR OTHERWISE, EVEN IF NEXEN SHALL HAVE BEEN ADVISED OF THE POSSIBILITY OR LIKELIHOOD OF SUCH POTENTIAL LOSS OR DAMAGE. For all of the purposes hereof, the term "consequential damages" shall include lost profits, penalties, delay damages, liquidated damages or other damages and liabilities which Buyer shall be obligated to pay or which Buyer may incur based upon, related to or arising out of its contracts with its customers or other third parties. In no event shall Nexen be liable for any amount of damages in excess of amounts paid by Buyer for Products or services as to which a breach of contract has been determined to exist. The parties expressly agree that the price for the Products and the services was determined in consideration of the limitation on damages set forth herein and such limitation has been specifically bargained for and constitutes an agreed allocation of risk which shall survive the determination of any court of competent jurisdiction that any remedy herein fails of its essential purpose.

Inspection

Buyer shall inspect all shipments of Products upon arrival and shall notify Nexen in writing, of any shortages or other failures to conform to these terms and conditions which are reasonably discoverable upon arrival without opening any carton or box in which the Products are contained. Such notice shall be sent within 14 days following arrival. All notifications shall be accompanied by packing slips, inspection reports and other documents necessary to support Buyer's claims. In addition to the foregoing obligations, in the event that Buyer receives Products that Buyer did not order, Buyer shall return the erroneously shipped Products to Nexen within thirty (30) days of the date of the invoice for such Products; Nexen will pay reasonable freight charges for the timely return of the erroneously shipped Products, and issue a credit to Buyer for the returned Products at the price Buyer paid for them, including any shipping expenses that Nexen charged Buyer. All shortages, overages and nonconformities not reported to Nexen as required by this section will be deemed waived.

Limitation on Actions

No action, regardless of form, arising out of any transaction to which these terms and conditions are applicable may be brought by the Buyer more than one year after the cause of action has accrued.

nexen[®]

Nexen Group, Inc.
560 Oak Grove Parkway
Vadnais Heights, MN 55127

800.843.7445
Fax: 651.286.1099
www.nexengroup.com

ISO 9001 Certified